


Smart Classroom (New) Review

Step 1: Touch the screen to activate. The screen may appear dark; it is in sleep mode.


Step 2: Select **System on**



Step 3: A red count-down page will show on the screen.




Step 4: The main screen



On the right side of the main screen you will see this control panel all the time, no matter what source/tabs on the top of the screen you have chosen. Use it to control volume and lights.

Step 5: Select a **source/tab** on the top of the screen







You have 5 sources to select:

- **1** allows VHS/DVD/TV display
- **2** switches to the document camera for notes and transparencies
- **3** projects from the laptop. You can select the choice of the laptop already in the room or your own. You need to connect the plug sitting on the desk with your own laptop is using your own.
- **4** controls the projector.
- **5** shuts down the system

Center for the Enhancement of Teaching & Learning

Troubleshooting Problems in Smart Classrooms

Problem		Solution
<p>The monitor on the laptop displays the image but will not project the image onto the screen.</p>		<p>On the laptop keyboard, press Fn & F3 together for Gateway computers, Fn & F8 for Dell computers. You may have to press the keys more than once. The Fn key is in the lower-left part of the keyboard, and F keys are on the top row of the keyboard.</p>
<p>Only half the image shows up on the screen</p> <p>Or</p> <p>The computer image is off to the side.</p>		<p>Adjust the H. Shift option (circled in blue in the picture) on the podium's input panel that plugs into your own laptop.</p>
<p>The projector will not turn on. The projector will not display an image from any source.</p>		<p>The projector did not have a chance to cool down before the system was turned on again. Turn the system off by shutting down the system (the big green shut down button under the ShutDown tab on the top). Wait until the projector fan stops (about 90 seconds) and turn the system back on again.</p>
<p>Other problems and Questions</p>		<p>Call the Technical Support Center by picking up the phone in the drawer; it will call automatically. The direct line is 351-4357.</p> <p>You can also refer to the more detailed 14-page manual on the podium for more instructions.</p>

Do NOT remove this copy. If you want to download this copy, please go to

<http://www.unco.edu/cetl/tutorials/smart.html>